

Средства защиты органов дыхания

Технические характеристики

По вопросам продаж и поддержки обращайтесь:

Алматы (727)345-47-04

Ангарск (3955)60-70-56

Архангельск (8182)63-90-72

Астрахань (8512)99-46-04

Барнаул (3852)73-04-60

Белгород (4722)40-23-64

Благовещенск (4162)22-76-07

Брянск (4832)59-03-52

Владивосток (423)249-28-31

Владикавказ (8672)28-90-48

Владимир (4922)49-43-18

Волгоград (844)278-03-48

Вологда (8172)26-41-59

Воронеж (473)204-51-73

Екатеринбург (343)384-55-89

Иваново (4932)77-34-06

Ижевск (3412)26-03-58

Иркутск (395)279-98-46

Казань (843)206-01-48

Калининград (4012)72-03-81

Калуга (4842)92-23-67

Кемерово (3842)65-04-62

Киров (8332)68-02-04

Коломна (4966)23-41-49

Кострома (4942)77-07-48

Краснодар (861)203-40-90

Красноярск (391)204-63-61

Курск (4712)77-13-04

Курган (3522)50-90-47

Липецк (4742)52-20-81

Магнитогорск (3519)55-03-13

Москва (495)268-04-70

Мурманск (8152)59-64-93

Набережные Челны (8552)20-53-41

Нижний Новгород (831)429-08-12

Новокузнецк (3843)20-46-81

Ноябрьск (3496)41-32-12

Новосибирск (383)227-86-73

Омск (3812)21-46-40

Орел (4862)44-53-42

Оренбург (3532)37-68-04

Пенза (8412)22-31-16

Петрозаводск (8142)55-98-37

Псков (8112)59-10-37

Пермь (342)205-81-47

Ростов-на-Дону (863)308-18-15

Рязань (4912)46-61-64

Самара (846)206-03-16

Санкт-Петербург (812)309-46-40

Саратов (845)249-38-78

Севастополь (8892)22-31-93

Саранск (8342)22-96-24

Симферополь (3652)67-13-56

Смоленск (4812)29-41-54

Сочи (862)225-72-31

Ставрополь (8652)20-65-13

Сургут (3462)77-98-35

Сыктывкар (8212)25-95-17

Тамбов (4752)50-40-97

Тверь (4822)63-31-35

Тольятти (8482)63-91-07

Томск (3822)98-41-53

Тула (4872)33-79-87

Тюмень (3452)66-21-18

Ульяновск (8422)24-23-59

Улан-Удэ (3012)59-97-51

Уфа (347)229-48-12

Хабаровск (4212)92-98-04

Чебоксары (8352)28-53-07

Челябинск (351)202-03-61

Череповец (8202)49-02-64

Чита (3022)38-34-83

Якутск (4112)23-90-97

Ярославль (4852)69-52-93

Россия +7(495)268-04-70

Казахстан +(727)345-47-04

Беларусь +(375)257-127-884

Узбекистан +998(71)205-18-59

Киргизия +996(312)96-26-47

Respiratory protection
Active for clean breathing



Procedure for the correct selection and use of respiratory protection systems

Basic measures

- Replacement, avoidance of hazardous substances, only then the use of PPE
- Resource planning (suitable personnel, aids and care equipment for disinfection, cleaning and proper storage of respiratory protection systems)
- Take organizational measures (provide necessary tests, manuals, certificates, evidence, operating instructions, training)
- Check physical and psychological effects on the wearer (e.g. claustrophobia)

Classification of pollutant types

Particles:

- Dry dusts (e.g. fibers, fine dust, smoke),
- Moisture-reacting (hygroscopic) dusts (e.g. crystalline, salts,
- Spores, germs, aerosols (e.g. spray mist, atomization products),
biohazards (bacteria, enzymes, viruses)

Gases and vapors:

- Free-floating molecules

- Water-soluble, fat-soluble, acidic and basic gases and vapors ==> Fat-soluble gases and vapors, e.g. solvents, do not always cause immediately recognizable damage; long-term damage and late effects are therefore usually inevitable



Risk analysis

- The oxygen content in the ambient air must be at least 17 vol%
- Complete identification of all hazardous substances and operating conditions
- Hazardous substance, chemical state (e.g. solid, liquid, gaseous)
- Quantity and exposure conditions of hazardous substances in the work process
- Operating temperatures and pressures ==> Changes can significantly influence the protective effect of the system!
- Description of the work steps in the processing taking into account the temperatures and pressures prevailing
- Room and environmental conditions
- Room temperature, warm or hot surfaces
- Indoor climate, e.g. ventilated or extracted rooms ==> usually leads to a reduction of protective measures
- Closed rooms without extraction, boilers, containers ==> usually necessarily leads to an increase in protective measures
- Exposure to aerosols or moisture, fog, etc.
- Working hours before and after contamination
- Further processes – e.g., decontamination, exposure to decontaminating agents
- Coordination with the remaining PPE (clothing, foot protection, hand protection, head protection, etc.)

Planned gestation period

- Disposable masks for short wearing times or changing staff
- Reusable masks for more frequent wearing times or for permanent staff
- Powered respiratory protection systems for longer periods of wear

По вопросам продаж и поддержки обращайтесь:

Алматы (727)345-47-04

Ангарск (3955)60-70-56

Архангельск (8182)63-90-72

Астрахань (8512)99-46-04

Барнаул (3852)73-04-60

Белгород (4722)40-23-64

Благовещенск (4162)22-76-07

Брянск (4832)59-03-52

Владивосток (423)249-28-31

Владикавказ (8672)28-90-48

Владимир (4922)49-43-18

Волгоград (844)278-03-48

Вологда (8172)26-41-59

Воронеж (473)204-51-73

Екатеринбург (343)384-55-89

Иваново (4932)77-34-06

Ижевск (3412)26-03-58

Иркутск (395)279-98-46

Казань (843)206-01-48

Калининград (4012)72-03-81

Калуга (4842)92-23-67

Кемерово (3842)65-04-62

Киров (8332)68-02-04

Коломна (4966)23-41-49

Кострома (4942)77-07-48

Краснодар (861)203-40-90

Красноярск (391)204-63-61

Курск (4712)77-13-04

Курган (3522)50-90-47

Липецк (4742)52-20-81

Магнитогорск (3519)55-03-13

Москва (495)268-04-70

Мурманск (8152)59-64-93

Набережные Челны (8552)20-53-41

Нижний Новгород (831)429-08-12

Новокузнецк (3843)20-46-81

Ноябрьск (3496)41-32-12

Новосибирск (383)227-86-73

Омск (3812)21-46-40

Орел (4862)44-53-42

Оренбург (3532)37-68-04

Пенза (8412)22-31-16

Петрозаводск (8142)55-98-37

Псков (8112)59-10-37

Пермь (342)205-81-47

Ростов-на-Дону (863)308-18-15

Рязань (4912)46-61-64

Самара (846)206-03-16

Санкт-Петербург (812)309-46-40

Саратов (845)249-38-78

Севастополь (8892)22-31-93

Саранск (8342)22-96-24

Симферополь (3652)67-13-56

Смоленск (4812)29-41-54

Сочи (862)225-72-31

Ставрополь (8652)20-65-13

Сургут (3462)77-98-35

Сыктывкар (8212)25-95-17

Тамбов (4752)50-40-97

Тверь (4822)63-31-35

Тольятти (8482)63-91-07

Томск (3822)98-41-53

Тула (4872)33-79-87

Тюмень (3452)66-21-18

Ульяновск (8422)24-23-59

Улан-Удэ (3012)59-97-51

Уфа (347)229-48-12

Хабаровск (4212)92-98-04

Чебоксары (8352)28-53-07

Челябинск (351)202-03-61

Череповец (8202)49-02-64

Чита (3022)38-34-83

Якутск (4112)23-90-97

Ярославль (4852)69-52-93

Россия +7(495)268-04-70

Казахстан +(727)345-47-04

Беларусь +(375)257-127-884

Узбекистан +998(71)205-18-59

Киргизия +996(312)96-26-47

эл.почта: jsw@nt-rt.ru || сайт: <http://jws.nt-rt.ru/>